



HopRockettm

Operation, Assembly & Maintenance Manual

Congratulations on your purchase, and thank you for selecting the HopRockettm from Blichmann Engineering. We are confident that it will provide you years of service and many gallons of outstanding beer. The HopRockettm is a multi use product. It can function as a hopback to add hop aroma to your wort after the boil, it can be used in your dispensing system to add fresh hop aroma as you pour your finished beer. It can also act as a general inline filter. This manual will familiarize you with the assembly and use of the HopRockettm so please read it thoroughly for safe operation and best performance.

**** PLEASE READ THOROUGHLY PRIOR TO USE FOR IMPORTANT SAFETY INFORMATION ****

Warning! The HopRockettm is obviously hot during use as a hopback and scalds and burns are an inherent and ever-present hazard of brewing! Always use protective gloves, long sleeve shirts, long pants, and protective footwear when brewing.

During operation, and particularly when used as an inline hop infuser in your dispensing system, you must **never exceed the rated pressure of 40 PSI (275 KPa)**.

If you do not understand the proper use of the product or have any questions, contact your retailer or Blichmann Engineering (www.BlichmannEngineering.com) before use.

Assembly & Installation:

Ensure you have the following parts for your HopRocket $^{\rm tm}$ as shown in Fig 1.

- 1 Main canister
- 1 Cone shaped cover with coarse screen installed with wing nut
- 1 Fine perforated screen with black silicone wiper seal
- 1 Strainer cup assembly (perforated cylinder and domed cap)
- 1 4" stud with one hex nut and 2 wing nuts
- 1 Large black silicone o-ring
- 1 Band clamp
- ${\tt 1-T-bolt} \ for \ the \ band \ clamp$



General Information:

The HopRockettm can be used as a hop-back, an inline hop infuser (Randalizer) and a general purpose particulate filter. However, the product is intended for <u>whole hops only</u>. Pellet hops will pass through the filter screen and in excessive quantities will plug it. For this reason we do not recommend it for recirculation type chilling systems since all of the particulates and trub will be forced through the hops in the HopRocket and may lead to plugging of the unit. Please use the following guide for capacity and flow recommendations for successful operation of the product. Since hops and individual systems vary significantly some experience and adjustments of flow and technique may be needed.

<u>Hop-back operation</u>: use of the cylindrical insert is recommended in this application to increase flow capability through the product. A maximum of 30z of whole hops is allowed with the insert in place. Using more hops than this will damage the product as the hops swell. In addition, limit flow to a maximum of 1 GPM (3.8L/min) to avoid compacting the hop bed which will plug the unit.

<u>Hop Infuser:</u> it is not necessary to use the cylindrical insert in this application since the hops are much less restrictive and less likely to compact at cold temperatures. Max capacity without the insert is 4oz for this application. It is recommended that the 4" stud be installed so that hop particles don't pass through the stud hole in the screen. Particles of this size may plug a 3/16" ID beer hose.

<u>General filtration</u>: flow rate will be highly dependent on the type and quantity of material being filtered. Experimentation with your specific system and process will be required.

Sanitation:

Caution: do **NOT** use any cleaner or sanitizer containing **chlorine** such as bleach. Over time, this will pit and erode stainless steel.

Any other non-chlorine sanitizer is acceptable to use. Iodophor[™] or StarSan[™] both work very well and do not require rinsing.

Disassemble all parts and soak in sanitizer. It is not necessary or recommended to soak the band clamp or t-bolt in sanitizer since these parts do not contact the wort. Over time this can damage the threaded surfaces of the clamp.

To assemble the HopRockettm it is easiest to use a carboy drainer/stacker to rest the canister on in an inverted position as shown in Fig 2. Install the threaded stud into the hole in the fine perforated screen using the hex nut and the wing nut as shown in Fig 3. Then install the perforated cylinder and cap over the stud and secure with the remaining wing nut as shown in Fig 4.

Caution: DO NOT over tighten the wing nut or you may damage the product! A slight pressure is all that is needed to hole the cylinder securely in place.

Lastly, install the black silicone wiper seal onto the fine perforated screen and insert it into the canister pushing it all the way down until it seats on the ledge at the bottom of the canister as shown in Fig 5.

TIP: It is easier to install the assembly into the canister walls if they are still wet from the sanitizer.

Fill the HopRockettm with the desired amount of whole hops (up to 30z) as shown in Fig 6 and then install the black o-ring on the top.

NOTE: <u>Pellet hops will not work in this product</u> and will simply pass through the fine perforation. I in excessive quantities they may plug the unit.

NOTE: Immersion recirculation chillers may cause this unit to plug since all particulates and trub will pass through the filter multiple times.

Caution: do NOT exceed 3oz of whole hops when using the cylindrical filter insert! Hops expand when they are wetted and this may cause damage to the coarse screen and make the product more prone to plugging and excessive restriction.

Next, place the coarse screen on the cone shaped cover and affix it with the wing nut as shown in Fig 7. A gentle tightening is all that is required. Then place the cone cover assembly on the canister as shown in Fig 8. Lastly, install the band clamp and tighten firmly by hand as shown in Fig 9.

Note: ALWAYS apply a dab of Vaseline or drop of oil on the threads of the draw bolt before each use to prevent wear and galling of the threads. Galled or warn threads are NOT covered under warranty.

At this time, invert the HopRockettm and you're ready to install it in your system!









Operation of the HopRockettm as a hopback:

The HopRockettm is manufactured with ½" male NPT fittings on each end. We recommend Blichmann Engineering QuickConnectortm fittings as shown in Fig 8 but any suitable fitting will work with the product. Our line of QuickConnectorstm (Fig 10) are available in straight, 90 deg, and ¼" flare configurations and are ideal for this application. See our web site for more details.

Warning! Always securely fasten the hoses to the product with hose clamps to prevent a hose from slipping off during use and possibly causing severe burns!

<u>Note that the mating fittings are NOT included with the product!</u> Each brewer prefers their own hose size and fitting type for their brewery and intended application so we have not included these parts.

Important! The location of the HopRockettm in your installation is very important. Please note that the BOTTOM is the INLET of the HopRockettm and the TOP is the OUTLET of the unit. Connecting it the opposite way will cause an airlock and the product will not function properly! The product label has arrows showing the direction of flow. The outlet fitting is located on the top of the canister to allow the air to naturally purge from it.

Install the HopRockettm in the following sequence, depending on your system configuration:

<u>With Pump and counterflow chiller</u>: Brew Pot \rightarrow Pump \rightarrow HopRockettm \rightarrow Chiller \rightarrow Fermentor

With gravity drain and counterflow chiller:

Brew Pot (at least 4ft (1.2M) above fermentor) \rightarrow HopRockettm \rightarrow Chiller \rightarrow Fermentor

<u>With immersion chiller</u>: Brew Pot \rightarrow Pump (if used) \rightarrow HopRockettm \rightarrow Fermentor Note: hot extraction of the hop oils is much more efficient so we recommend a counterflow chiller for maximum performance.

Operation is as simple as starting your pump or opening your drain valve on the brew pot and allowing the wort to flow through your HopRockettm and counterflow chiller.

Tip: Allow the wort to fill the HopRocket by gravity so that the air will purge and the hops will absorb water slowly. Turning on the flow at full capacity immediately will compact the hop bed and potentially plug the unit.

Tip: Make sure that all hoses and components are NOT filled with wort prior to starting your pump or opening your drain valve. Components that are filled with liquid may cause your system to air-lock and flow will be prevented.

Flow Performance & Restriction: High wort flow rates and large amounts of particulate material (trub, pellet hops, Irish moss etc) will increase the restriction of your hop bed as they filter out these particles. This varies depending on hop type, trub volume, and pellet hop volume. This increased restriction will reduce the flow through the HopRockettm and potentially compact the hop bed. Similarly, greater amounts of hops will increase the restriction of the hop bed. Lastly, hop flowers become very soft when exposed to hot liquids and may pack together if too much pressure is applied to them similar to a stuck mash. This can be prevented by using a slower flow rate and minimizing the amount of particulates entering the HopRockettm. Our HopBlockertm kettle filtration system is a great companion for the HopRockettm. Using a pump, you should expect to achieve about 1 GPM (3.8 LPM) with 30z of hops, and about 1.5 GPM (5.7 LPM) with 20z of hops. Gravity systems will vary with elevation above the fermentor. We recommend at least 4ft (1.2M) of elevation for good performance.

Operation of the HopRockettm as an Infuser:

The HopRockettm makes an outstanding hop infuser (Randalizer) for your beer dispensing system. This adds a unique bright hop aroma to your beer. Assembly and loading with hops is identical to the hopback instructions. Note that it is not necessary to use the cylindrical filtration insert when using as a hop infuser.

The main difference is the adapters used to connect it to your dispensing lines. Blichmann Engineering offers 1/4" optional male flare

QuickConnectorstm that make this an easy install onto your standard beer dispensing hoses. See Fig 11.

Warning! <u>NEVER</u> exceed 40 PSI (275 KPa) with this product! A dangerous overpressure can cause severe injury or death.

Simply locate the HopRockettm between the keg and the tap making sure that the HopRockettm remains inside the refrigerator at the same temperature as the keg to minimize foaming.

We do recommend that you purge the HopRockettm with CO₂ prior to filling with beer, but this isn't an absolute requirement since the HopRockettm will naturally purge entrained air. To fill with beer, place it in the upright position (outlet fitting facing upward) and open your tap. It may take a minute or so for beer to come out of the line, and it may be foamy for the first couple pints. After you have purged all the air and CO₂ out of the system we recommend inverting the unit for dispensing. This will allow you to get every drop out of beer out of the HopRockettm when your keg runs dry.

Disassembly & Storage:

To disassemble the HopRockettm simply remove the band clamp and dump out the hops.

Warning! The HopRockettm and hops are obviously hot during use as a hopback and scalds and burns are an inherent and ever-present hazard of brewing! Always use protective gloves, long sleeve shirts, long pants, and protective footwear when brewing.

To remove the fine perforated screen insert a screw driver or the end of a racking cane to unseat it from the ledge as shown in Fig 12. Then simply scrub off any hop particles, remove all seals and soak in any stainless compatible sanitizer. Dry parts thoroughly and reassemble for storage. If desired, you can also soak the parts in Powdered Brewery Wash (PBW) in lieu of scrubbing.

Caution: It is not necessary or recommended to soak the band clamp or t-bolt in sanitizer. Over time this will wear at the threads.



Warranty

Blichmann Engineering products are warranted to be free of defects in materials and workmanship for a period of 1yr from the date of purchase (proof of purchase required). Specifically excluded from this warranty is normal wear and tear, damage from abuse, misuse, failure to follow cleaning and maintenance procedures, and thread galling or breakage from over tightening. Blichmann Engineering is not responsible for incidental or consequential damage arising from use or misuse of this product. This product is intended for home use ©Blichmann Engineering, LLC 2015 only. No warranty or guarantee of suitability (express or implied) is given for commercial use of this product. Product manual may contain more specific warranty information unique to each product.

Blichmann Engineering must be notified within 7 days of the delivery date of any hidden shipping damage. Owner is responsible for shipping damage outside of this time period. Customer is responsible to keep all original packing material for warranty returns – Blichmann Engineering, LLC is not responsible for damage from improperly packaged warrantee returns and these repair costs will be the responsibility of the customer. Resolution of warranty claims will be by repair or replacement and will be the decision solely of Blichmann Engineering. Shipping costs for warrantee returns are covered only for the contiguous United States. User is responsible for packaging costs and shipping damage if not returned in original packing. Approval for return (RMA) must be provided by Blichmann Engineering prior to any return.